

Cleaning Instructions for Futronic Fingerprint Readers

In order to maintain the life and warranty of your Futronic fingerprint reader, please follow these simple guidelines:

Keep the reader window surface clean, as described in the following section.

Do not allow users to hit the reader or the reader shell with any metal or solid objects as the shell may be broken by abuse.

Cleaning the Futronic Fingerprint Reader

To capture consistently high quality fingerprint scans, the fingerprint reader must be clean.

To clean the fingerprint reader, use a soft non abrasive cotton cloth moistened slightly with alcohol (not soaking wet as there should not be alcohol left on the surface). Rub the cloth gently on the glass surface and then wipe the surface clean with a dry part of the cloth.

Warning

To protect against the risk of damage to the fingerprint reader:

- Do not pour any liquid or chemicals directly on the reader window.
- Never rub the window with an abrasive material.