



Dear Valued Customer,

Thank you for purchasing the BIOSID™ Mobile Device. A portable, fast and reliable biometric identity enrollment and verification from any location on 1 hand.

In the enclosed package, you will have:

- 1) BIOSID Tablet
- 2) Power Supply (charging cable USB to USB Mini)
- 3) 2 x PVC Contact card (C7 - 144 KB memory)
- 4) 2 x PVC Contactless card (C8 – 164 KB memory)
- 5) Instruction manual (digital format is found within the tablet and an external download can be found here: www.cardlogix.com/product/biosid-biometric-tablets-mobile-identity-solutions/)

Please fill out the Registration Form found via the following URL. Please submit the form immediately in order to receive important product updates. Product Registration Form: <https://www.cardlogix.com/support/product-registration/>

If you require customization of your BIOSID™ software to show your smart card design or how your smart card would look, please let us know and we can make the modifications for you. Please contact our sales team at sales@cardlogix.com or call us at +1 (949) 383-1312.

We hope that you will be pleased with the BIOSID™, but if something is not right, contact us now so that we can make it right.

Sincerely,

Your Smart Card Solution provider, CardLogix

Operation:

We strongly recommend that you plug in the BIOSID™ for a full charge before use. All BIOSID™ are fully charged when leaving our facility. However, in transportation, it might lose its charge. Please use the included cable and adapter for charging.

To start the BIOSID™, please press on the power button located on the top left side of the tablet (the black button has a square on it). The ANDROID word and logo will appear on the screen. It will take a few minutes for the tablet to show its full screen. (see detailed information on the back of this sheet)

When the BIOSID™ screen shows up, you will have the date and time in a box in the middle of the screen. Just use your finger and move the box upwards. You will then see BIOSID™ on the main screen.

From the main screen, you have a few options:

- 1) Start the enrollment by clicking enrollment
 - a. As soon as you start the enrollment, continue each step presented on the screen and you will have an enrolled card. Please be patient at times, the BIOSID might take a few seconds to move from one enrollment process to another.
- 2) Click on the “ Gear” on the top left of the screen to setup your application (select the biometric enrollment or testing, language, etc...)

